

Engineering Schematic

Distributed AGV Onboard Network & Telemetry Architecture

This document details the hardware configuration, wiring logic, and network topology for implementing a decoupled AGV communication system using Valtoris modular nodes. This architecture eliminates the single points of failure inherent in integrated "All-in-One" gateways and minimizes chassis wiring.

1. Node Deployment & Wiring Logic

Node A: The Connectivity Backbone (VT-LTE400)

Function: Handles WCS/AGVS uplink via 802.11r fast roaming with 4G LTE failover.

- Placement:** Highest point of the AGV chassis (ensures optimal RF line-of-sight and avoids motor EMI).
- Power Input:** 9-24V DC (Connects directly to AGV battery system; wide voltage tolerates motor startup drops).
- Network Role:** Acts as the central switch and DHCP Server for all onboard edge nodes.

Node B: Serial-to-Ethernet Bridge (1CH-RS232/485/422-ETH)

Function: Converts ground-level Modbus RTU/ASCII signals (BMS, Servo Drives, RFID) to Modbus TCP.

- Placement:** Bottom chassis, adjacent to motor drives. **Goal: Keep serial cables under 0.5 meters.**
- Wiring (RS485):** Pin T/R+ to Drive A+, Pin T/R- to Drive B-. (Ensure common ground if drives lack optical isolation).
- Uplink:** Standard Cat5e/Cat6 Ethernet cable to VT-LTE400 LAN Port 1.

Node C: Discrete I/O Edge Node (4CH-IO-ETH)

Function: Captures physical signals (bumpers, limits) and triggers outputs (alarms, relays).

- **Placement:** Chassis perimeter, near mechanical bumpers or photoelectric sensors.
- **Wiring (DI):** Supports dry/wet contacts. Connect Bumper switch to DI_1 and COM.
- **Wiring (DO):** Connect DO_1 to the 24V Warning Beacon relay.
- **Uplink:** Standard Cat5e/Cat6 Ethernet cable to VT-LTE400 LAN Port 2.

2. Recommended IP Address Assignment

Device Node	Interface	Recommended IP (Static)	Gateway
VT-LTE400 (Main Router)	LAN / WLAN	192.168.1.1	-
AGV IPC (Main Controller)	ETH0	192.168.1.2	192.168.1.1
1CH Serial Node	LAN	192.168.1.10	192.168.1.1
4CH I/O Node	LAN	192.168.1.11	192.168.1.1

Valtoris Industrial Connectivity

For technical support and firmware updates, visit www.valtoris.com

LEGAL DISCLAIMER: The network topologies, wiring logic, and IP configurations provided in this document are intended for conceptual and reference purposes only. Valtoris makes no warranties, expressed or implied, regarding the applicability of this architecture to any specific machine design. It is the responsibility of the system integrator or OEM to ensure that all electrical wiring, safety protocols, and radio frequency deployments comply with local industrial regulations and safety standards (e.g., ISO 3691-4). Valtoris shall not be held liable for any equipment damage, production downtime, or personal injury resulting from the implementation of this reference architecture.